

Sony Ericsson K800i disassembly

Tools required: Torx 6 screwdriver, Size 0 Phillips screwdriver

Remove the two screws at the bottom of the phone with the torx 6 screwdriver. Remove the other two screws with the Phillips screwdriver



Lift the antenna cover away from the phone. It unclips at the top of the phone and needs a little force to remove



Remove the two torx 6 screws at the top of the phone which are revealed after removing the antenna cover



Pull the front cover away at each side so that it releases



The phone will now be
in two parts, as below



Wiggle and pull the
keypad assembly up,
away from the phone
and it will pop off



The screen assembly is held on by two clips at each side of the phone, indicated below. Unclip them to remove the screen assembly



Unclip the ribbon which hold the screen assembly to the circuit board of the phone. It attaches like a plug and socket



